


Step 1 - Set up a Point-to-Point Link


Follow the steps in the Altum AC Quick Start Guide “Point-to-Point Link Configuration” to setup a Altum AC link. You can find this on the Trango support site <http://support.trangosys.com>.

Step 2 - Install the 2.4 GHz Omni Antennas


Install two 2.4 GHz omni directional antennas to the two N-Type connectors on the bottom of the Station.



2.4 GHz Omni Antennas




N-Type Connectors



2.4 GHz
Omni Antennas
Installed

Step 3 - Login to the Station Unit

- ① Navigate to a web browser and enter the IP address for the Station. Our example in the “Point-to-Point Link Configuration” Quick Start Guide is **192.168.1.20**
- ② Enter your Username and Password. The default Username is *admin* and Password is *trango* (case sensitive).
- ③ Log in to the radio by clicking **Login**




Step 4 - Edit the Station's WiFi Settings

- ① Navigate to **Network > Wifi**. In the first row that is labeled **2.4 GHz 802.11bgn Radio**
- ③ click **Edit**



Set the following:

- ④ Country Code - US-PTP-2
- ⑤ Wireless Profile - 802.11g+n
- ⑥ Channel Spectrum Width - 20/40 MHz
- ⑦ Channel - Auto
- ⑧ Transmit Power - Max
- ⑨ Mode - Access Point
- ⑩ ESSID - A600-2
(Note: This is the default ESSID. You can change this name if you'd like.)
- ⑪ Click **Save & Apply**




Step 5 - Set up Wireless Security (Optional)

① Navigate to *Network* > ② *Wifi*. In the first row that is labeled **AP** 2.4 GHz 802.11bgn Radio ③ click  **Edit**




The screenshot shows the 'Network' tab with 'Wifi' selected. Under 'Wireless Overview', the '2.4 GHz 802.11bgn Radio' is listed. The 'Edit' button is circled with a 3.

③ Under *Interface Configuration* select the *Wireless Security* tab. ④ In the *Encryption* drop down menu select *WPA2-PSK*.



The screenshot shows the 'Interface Configuration' page with the 'Wireless Security' tab selected. The 'Encryption' dropdown menu is open, and 'WPA2-PSK' is selected and circled with a 4.


⑤ Select *Cipher-Auto* and ⑥ set the password key. This key will be required by connected users on the Wi-Fi. ⑦ Click  **Save & Apply**



The screenshot shows the 'Interface Configuration' page with the 'Wireless Security' tab selected. The 'Cipher' is set to 'Auto' (circled with 5) and the 'Key' is set to a password (circled with 6). The 'Save & Apply' button is circled with a 7.

Step 5 - Enable the 2.4 GHz Wireless Network

① Under *Device Configuration* > *General Setup* tab > Select *Enable*. ② Click  **Save & Apply**



The screenshot shows the 'Device Configuration' page with the 'General Setup' tab selected. The 'Enable' button is circled with a 1.


Step 6 - View Connected Users

To view connected users on the Wi-Fi access point, ① Navigate to *Status* > ② *Overview*.



The screenshot shows the 'Status' tab with 'Overview' selected.

Under *Associated Stations* the connected users will be displayed.



The screenshot shows the 'Status' tab with 'Overview' selected. The 'Associated Stations' table is displayed below the radio configuration details.

| MAC-Address | Network | Device Name | Last IP | Signal | Signal/Chains | Noise | TX Rate | RX Rate | TX-CCQ |
|-------------------|---------|-------------|---------|---------|---------------|---------|------------|--------------|--------|
| A4:67:06:06:51:BB | A600-2 | | | -43 dBm | -62,-43 dBm | -95 dBm | 0.0 Mbit/s | 65.0 Mbit/s | 25 % |
| 78:4B:87:F4:A4:5E | A600-2 | | | -42 dBm | -62,-42 dBm | -95 dBm | 0.0 Mbit/s | 107.3 Mbit/s | 25 % |